



Lens Recommendations for Drill Mounts

High Index materials will crack or chip around the drill mount of rimless frames. Maybe not today, maybe not tomorrow, but they will eventually crack. Avoid high index materials in drill mounts. We know a reputable lab that claims the Seiko 1.67 is less prone to this problem, but we still steer our patients who need high index lenses into semi-rimless frames.

Trivex is your best option for rimless frames. Will not crack or chip around the drill mount. Polycarbonate is probably your second best bet, but it will eventually crack like high index lenses, just not as quickly.

Copyright 2014 OpticianU